VSX Remote Control Buttons

Call-Hang Up Button

Adjust the camera, navigate through menus

Enter Button; Confirm current selection

Return to previous screen

Switch between near-site and far-site camera views

Select camera or other video source

Show/Hide picture-in-picture

Display onscreen keyboard to enter text

Store camera positions followed by numbers

Start and stop sending content to far sites

Use Keypad to enter number or IP address.